

2.2 WELL-CONDITIONED AND ILL-CONDITIONED TRIANGLES

A triangle is said to be well conditioned when no angle in it is less than 30° or greater than 120° . An equilateral triangle is considered to be the best-condition or ideal triangle [Figs 2.1 (a) and (b)].

Well-conditioned triangles are preferred because their apex points are very sharp and can be located by a single 'dot'. In such a case, there is no possibility of relative displacement of the plotted point.

A triangle in which an angle is less than 30° or more than 120° is said to be ill conditioned [Fig. 2.1(c)].




Fig. 2.1(a) Ideal Triangle




Fig. 2.1(b) Well-Conditioned Triangle




Fig. 2.1(c) Ill-Conditioned Triangle

Ill-conditioned triangles are not used in chain surveying. This is because their apex points are not sharp and well defined, which is why a slight displacement of these points may cause considerable error in plotting.

Types Of Triangles

There are basically six different **types of triangles** with respect to the length and measure of the lines and angles of a triangle, respectively. To recall, a triangle is a specific type of polygon having only three sides and three angles. Based on these specifications and design the [properties of triangles](#) are defined for all its different types.

As the name suggests, a “triangle” is a three-sided polygon having three angles. The sum of all interior angles of a triangle will always add up to 180 degrees. This is called the [angle sum property of triangle](#). Also, a triangle has many properties. Let us discuss in detail about the triangle types.

Table of contents:

- [Six types](#)
- [Based on Sides](#)
 - [Scalene](#)
 - [Isosceles](#)
 - [Equilateral](#)

[Based on Angles](#)

- [Acute-angled](#)
- [Obtuse-angled](#)
- [Right-angled](#)

Six Types of Triangles

Triangles can be broadly classified into two types, which are:

- Triangles based on the lengths of their sides
- Triangles based on their interior angles

These two triangle types are explained here along with their further classifications.

Based on their Sides	Based on their Angles
Scalene Triangle	Acute Triangle
Isosceles Triangle	Obtuse Triangle
Equilateral Triangle	Right Triangle

We will discuss all the above triangles broadly in the next section to differentiate among all. Also, will see the properties of each triangle related to them.

Types of Triangles Based on Sides


According to the lengths of their sides, triangles can be classified into three types which are:

1. Scalene
2. Isosceles
3. Equilateral

Let us discuss them one by one.

Scalene Triangle


A scalene triangle has all side lengths of different measures. No side will be equal in length to any of the other sides in such a triangle. In a scalene triangle, all the interior angles are also different. The figure given below illustrates a scalene triangle. You can see how none of the sides is equal in length.



In the above-given figure, you can see that all the sides of the triangle seem to be unequal.

Isosceles Triangle


In an isosceles triangle, the lengths of two of the three sides are equal. So, the angles opposite the equal sides are equal to each other. In other words, an isosceles triangle has two equal sides and two equal angles. The figure given below illustrates an isosceles triangle.



In the above figure, we can see the two sides of the triangle appears to be equal, whereas the base of the triangle here is smaller than the other two sides.

Equilateral Triangle

In an equilateral triangle, all the lengths of the sides are equal. In such a case, each of the interior angles will have a measure of 60 degrees. Since the angles of an equilateral triangle are same, it is also known as an **equiangular triangle**. The figure given below illustrates an equilateral triangle.



In the above figure, all the three sides of the triangles are equal as well as all the interior angles equal to 60 degrees.

Types of Triangles Based on Angles


Triangles can be classified into three types with respect to their interior angles which are:

1. Acute-angled
2. Obtuse-angled
3. Right-angled

Let us discuss them.

Acute Triangle


An **acute triangle** is a triangle whose all the three interior angles are acute. In other words, if all interior angles are less than 90 degrees, then it is an acute-angled triangle. The figure given below illustrates an acute triangle.



In the above figure, we can see all the interior angles of the triangle, is less than 90 degrees, hence it is an acute triangle.

Obtuse Triangle


Obtuse triangles are those in which one of the three interior angles has a measure greater than 90 degrees. In other words, if one of the angles in a triangle is an obtuse angle, then the triangle is called an obtuse-angled triangle. The figure given below illustrates an obtuse triangle.



In the above triangle, we can see that one of the angles is more than 90 degrees. Hence, it is an obtuse triangle.

Right Triangle

A right triangle is a triangle in which one of the angles is 90 degrees. In a right-angled triangle, the side opposite to the right angle (90-degree angle) will be the longest side and is called the hypotenuse. You may come across triangle types with combined names like right isosceles triangle and such, but this only implies that the triangle has two equal sides with one of the interior angles being 90 degrees. The figure given below illustrates a right triangle.



In the above triangle, one among the three angles is 90 degrees, thus it is a right triangle.

Frequently Asked Questions on Types of Triangles

Write down the types of triangles classified based on its sides?

Based on the sides of a triangle, a triangle is classified into three different types, namely:
Scalene Triangle

Isosceles Triangle
Equilateral Triangle

Mention the classification of a triangle based on its angle.

Based on the angles of a triangle, a triangle is classified as:

Acute Triangle
Right Triangle
Obtuse Triangle

Define scalene, isosceles and equilateral triangle.

In a scalene triangle, all the sides of a triangle are of different length. In an isosceles triangle, two sides of a triangle are of the same measure. In an equilateral triangle, all the sides of a triangle are of the equal length.

Define acute, obtuse and right triangle.

In an acute triangle, all the angles of a triangle are less than 90 degrees.

In an obtuse triangle, one of the angles of a triangle is greater than 90 degrees.

In a right triangle, one angle measures 90 degrees and the other two angles are acute.

Can an acute triangle be a scalene triangle?

An acute triangle can be a scalene triangle, isosceles triangle or equilateral triangle. The acute triangle can be drawn if the triangle has equal or unequal side lengths.